



Product Main Number 1999918728



Machine descaler, ABENA, For household appliances, without colour and perfume, 50 pieces

- ✓ Removes limescale
- ✓ Multiple uses
- ✓ Without colour and perfume

Product Description

Efficient machine descaler tablets that are suitable for removing limescale in both dishwashers and washing machines. The tablets clean pipes, filters and nozzles to keep your machine operational. Regular use extends the life of your machine.



Specifications

Base name	Machine descaler
Brand	ABENA
Features	For household appliances, without colour and perfume, 50 pieces
Directives, regulations and acts	(EC) No 648/2004
Dosage Instructions	1 tablet per wash

Instructions for use/application

Dishwasher: Place the tablet in the dosing compartment and run a programme of minimum 60°C in an empty dishwasher. Washing machine: Place the tablet in the drum and run a programme of minimum 60°C in an empty washing machine.

Packaging data

Unit	Contains	Length	Width	Height	EAN
cll	12 pck	37 cm	28 cm	27 cm	5703538497872
pck	50 pcs				5703538497865

<p>The product is used for washing machine cleaning.</p>	<p>The product requires use of eye protection.</p>	<p>The product can pose a health hazard.</p>
<p>The product requires use of protective gloves.</p>	<p>The product requires use of a protective suit.</p>	<p>The product does not contain color.</p>
<p>The product does not contain perfume.</p>	<p>The product is used for dishwashing machines.</p>	<p>The product is used for descaling.</p>